




# Set up

This page explains how to set up the organ to work with the laptop, each time you want to use it.

1. Turn on the laptop, and log onto the *Organ* account - no password needed.
2. Ensure the *WIDI Bud Pro* dongle is connected to a USB port on the side of the laptop and is slowly flashing blue  

3. The “other end” of the wireless link stays permanently connected to the organ so there is no need to touch the MIDI sockets on the organ console. We are no longer using the USB cable.
4. There are two toggle switches next to the MIDI sockets on the organ. Ensure the left hand one (*Stops On*) is **DOWN** and the right hand one (*Great Omni Receive*) is **UP**. These should not be changed.
5. Turn on the organ blower. Ensure all stops are **off** and the swell pedal is fully **closed**. The flashing light on the WIDI Bud Pro should stay on without flashing once it is connected to the organ.
6. Open OrganAssist and acknowledge the message about turning the stops off by clicking **OK**.  

7. Test the link by clicking one of the stops on the screen to engage it, then clicking on one of the manuals to play a note. You should hear a note. Conversely, play some notes on the physical manual and you should see the corresponding keys flash green on the screen.  


---

Revision #9

Created 3 February 2022 21:12:18 by Jonathan

Updated 4 February 2022 16:43:18 by Jonathan